

FIXING INSTRUCTION FOR HOOK & BAR SYSTEM

Mount steel bar & bracket assembly (either face fix as in illustration or fix on to top of loft floor) with the 2" x No. 10 Pan-head screws. Position hooks on rear edge of ladder, drill pilot holes and fix using CSK 1/4" no.10 screws.

In the case of Aluminium ladders, use the nuts and bolts provided if the hooks are not already attached.

